

Inspection of Flexible Riser Pipe with MEC-FIT[™]

K. Reber, Innospection Germany GmbH, Stutensee, Germany A. Bönisch, Innospection Ltd., Aberdeen, UK

Presented at the PPSA Seminar on 16th of November 2011 Marcliffe Hotel, Pitfodels, Aberdeen, UK


What is so difficult about the inspection of flexible riser pipe?



- Material is not homogeneous through the thickness of the wall
- Electrically conductive and insulating material is present
- Ferromagnetic and stainless steel (or duplex) is present
- Every pipe is different in its structure
- There is a pronounced anisotropy due to the helical winding


Layers of a flexible riser

innospection



UT pig internal measurement of a flexible riser







Courtesy of NDT Systems & Services AG

Experience in pigging flexible riser with MFL?




- Potential problem are remaining ferritic particles in stainless steel carcass.
- Particles from previous inspection (Rust) or magnetic steel bristles.
- Can lead to corrosion in the carcass.
- Cleaning pigs adapt bristle material.





PPSA Seminar, Aberdeen November 16th 2011



Switchable Permanent Magnet






- Adjust to ideal magnetisation level
- No electrical power required
- Fail safe


Additional Hall Sensors to monitor the flux level

innospection




Optimum magnetisation level





• Compare open and closed circuit to obtain below curve



Flexible Riser Pipe innospection Testing 05/11/2009

Flexible Riser Pipe Lighter Option for ROV deployment






E 573552 N 6463575 10 30 57 10 Nov 10 H 337 D 68 5 Lynx Task 10" Oil Riser FRIT trials



Scanning up/down in several steps to achieve full coverage
Light for ROV deployment


•In cooperation with








Radiography by Oceaneering






Scans using MEC-FIT









•In cooperation with



Spin-offs Crawler with UT Sensor



